



Installation, Operational & Maintenance Manual



Packaged Air Cooled
Split System Air Cooled
Packaged Water Cooled
Tank & Pump Skids

NOTE

- **This equipment should only be installed and started by a certified refrigeration mechanic who is familiar with chiller equipment.**
- **Failure to follow accepted refrigeration practices during installation and start-up will void the equipment warranty.**
- **All field piping and wiring must conform to the requirements of the manufacturer as well as all applicable national and local codes.**

Table of Contents

Receiving	4
Uncrating	4
Rigging	4
Unit Location	4
Mounting	5
Piping – General	5
Chilled Fluid Piping	5
Refrigeration Piping	6
Wiring	7
Compressor Oil Charge	7
Leak Testing Refrigeration Side	8
Leak Testing Chilled Fluid Side	8
Evacuation – Refrigeration Side	8
Refrigerant Charging	9
Start-Up – General	10
Start-Up – Compressor Precautions	11
Start-Up – Microprocessor Operation	12
Start-Up – Microprocessor – Alarm Conditions and Indications	13
Start-Up – Microprocessor – Review Mode and Programming	14
Start-Up – Remote Microprocessor – Review Mode and Programming	14
Operational Check	18
System Controls – Electrical	20
System Controls – Mechanical	22
Warranty Repairs	23
Terms & Conditions of Sale	24
Pipe Sizing	25
Recommended Remote Condenser Line Sizes	26
Preventative Maintenance Schedule	27
Warranty Activation Form	28
Tables:	
Pipe / Tube Support	5
Weight Liquid Refrigerant in Copper Tube	10
Remote Condenser Line Sizing	26
Warranty Labor Allowances	37
Graphs:	
Chilled Fluid Pipe Sizing	25

Receiving

When receiving equipment from Drake, each shipment must be checked against the bill of lading. **Shortages and shipping damage is the responsibility of the shipping carrier.** Both should be noted on the shipping receipt when the equipment is first received. Hidden damage should be brought to the carrier's attention as soon as it is discovered. In both cases, claims should be filed promptly with the carrier. Do not return damaged equipment to the manufacturer without prior approval.

Uncrating

The shipping skid can be used to aid moving equipment, such as to lift via forklift. The shipping skid should not be removed until the equipment is at the point of installation.

Rigging

Fork lifts or dollies are required for moving this equipment. When lifting from above, always use sufficiently long spreader bars to avoid lifting damage. On larger units, where lifting eyes are provided in the base frame, be sure to lift only from the base and use all eyes provided.

Unit Location

Units must be positioned with sufficient clearance on all sides for proper inspection, maintenance and airflow.

Allow at least 3 ft. for access into the compressor compartment. National Electric Code requires a minimum of 3 ft. in front of control panels rated 600V or less. More may be required depending on the peculiarities of the installation such as proximity to other live electrical parts. Local codes may require greater clearance.

Units with Air-cooled Condensers:

- Care must be taken to ensure an ample supply of fresh, clean air.
- Installing Indoors:
 - When installing indoors, an intake and exhaust air system capable of handling 1000 CFM per compressor horsepower must be supplied at zero static pressure.
 - In all cases, caution must be taken to avoid locating units in restricted spaces where heat build up at the condenser can occur.
 - Avoid locating multiple units such that the air discharge from one blows into the air intake of another.
- Installing Outdoors
 - For air-cooled units located outdoors AND intended for year-round operation, special attention must be paid to prevailing wind direction during colder weather.
 - If wind is blowing through the condenser, cycling or reducing the speed of the condenser fan may no longer be an effective means of head pressure control. This is normally not a problem with flooding types of head pressure control.

Avoid all overhangs, which may cause discharge air to be re-circulated through the condenser!

Units with any vertical-face condensers:

- One condenser height is the minimum distance that the condenser face may be located from a wall or obstruction.
- When placing (2) of these units side by side so that the condensers face one another, use twice the tallest condenser height as the minimum distance between units.

Units with any horizontal-face condensers:

- Allow at least (1) condenser width between the condenser and a single wall.
- If the unit is located in a well or has solid walls on more than one side, allow at least (1) condenser widths.
- If two or more units are placed side by side, allow at least (2) condenser widths between units.

Failure to follow these instructions will cause the unit to run inefficiently and may cause nuisance trips on various safety controls.

Mounting

Units must be installed in a level position, on a firm support. **Never use a wooden shipping skid as a permanent base.**

- For ground mounting, a suitably designed concrete slab is recommended. Raising the slab 4 to 6 inches above grade provides some protection from ground water.
- For roof mounting, a structural analysis by a qualified engineer may be required.

The unit should be mounted on suitably sized steel channels or beams. Vibration-absorbing pads or springs between the unit and mounting frame are recommended for vibration elimination.

Compressors that are spring-mounted are rigidly secured from the factory to prevent shipping damage. After mounting the unit and prior to startup, the following steps should be taken:

1. Loosen and remove the (4) nuts and washers used to hold the compressor firmly in place.
2. Remove and discard the (4) shipping spacers between the compressor and its mounting base.
3. Install the (4) rubber spacers, provided as loose items, over the compressor mounting stud
4. Reinstall the (4) nuts and washers removed in step 1 above leaving approximately 1/16" space between the nut and washer. This will allow the compressor to "float" on the mounting springs.

Piping – General

All field piping must conform to the requirements of the equipment, as well as all applicable national and local codes. Care has been taken to insure that factory piping is properly brazed, and all fittings and gasketed joints are tight. These may loosen or break during shipment & must be checked prior to start-up. All joints, especially threaded and gasketed joints, should be checked again after one to two weeks of operation. Take corrective action as necessary.

All lines must be supported. The distance between supports will vary with the diameter and wall thickness of the pipe or tubing used, the weight of the fluid being carried, as well as the number of valves and fittings in the line. Supports should be provided near changes in direction, at branch lines and particularly near valves. The weight of the tubing must not be carried through the valve body, since this may distort the valve and cause it to not function properly. Horizontal supports must be close enough to prevent sag, which would impose excessive stress on the pipes. Vertical supports must be close enough to adequately support the weight of the tube as well as to prevent sway caused by blowing wind. As a guide, the following table may be used:

Table 1. Pipe / Tube Support

Tube OD (in)	3/8 – 7/8	1-1/8	1 3/8 – 1 5/8	2-1/8	2-5/8	3-1/8
Nom. Pipe Size (in)	1/4 – 5/8	1	1-1/4	1-1/2	2	3
Max. Span (ft)	5	6	7	9	10	12

Chilled Fluid Piping

Various types of pipe may be used, but care must be taken to ensure that the material is compatible with the service for which it is intended. Line sizes should be based on the curves shown in Fig. 1, 2, and 3 on Page 21, and not on connection sizes at the chiller.

- **Chilled Fluid Lines** (See Line Size curves shown in Fig. 1, 2, and 3 on Page 26)
 1. Fluid lines should be kept as short and direct as possible.
 2. Lines should be sized for low pressure drop in order to minimize pump requirements.
 3. Lines must be insulated.
 4. Use insulation of sufficient thickness to prevent sweating, which can damage property or present a hazard to personnel.
 5. Piping must be a continuous loop with purge valves at high points.
 6. Expansion tanks are normally not required and their use is dependent on the peculiarities of the job.
 7. A continuous and steady fluid flow through the chiller's heat exchanger is necessary for proper system operation. If the fluid is being used to cool more than (1) process or machine, 3-way valves or bypass circuits may be required.
 8. Field supplied flow controls, meters or gauges may be required for proper operation.
 9. Field supplied strainer or filter is required in the return fluid line at the chiller. The fineness of the strainer mesh, or the filtering medium, used is dependent on local conditions. If no mesh fineness is defined, a mesh fineness of U.S. Mesh 14 to 35 is recommended to protect the chiller. **Failure to provide a strainer or filter will void all warranties.**

Refrigeration Piping

Packaged Chillers:

- All Packaged chillers leave the factory with the refrigeration side fully piped & charged.

Water-Cooled Chillers:

- Water-regulating valves for water-cooled condensers are shipped loose with the chiller, and **must be installed in the field.**
- Install on the condenser Leaving Fluid side or on the condenser Return to Fluid Source side.

Split-Systems:

- Split-System chillers require interconnecting refrigeration piping between the compressor/evaporator section & the condenser section.
- **Both sections leave the factory charged with refrigerant. Their combined charge is indicated on the compressor/evaporator data tag.** Additional refrigerant will have to be added in the field due to the interconnecting piping (see "System Refrigerant Charging").
- The discharge and liquid lines in both sections have shutoff valves with capped leads. **Never uncap these leads without checking the shutoff valves to be sure that they are fully closed and the units are ready for piping.**
- To prevent moisture in the air from condensing inside the tubes, **never leave refrigerant lines open when they are not being worked on, especially overnight.** This is especially important with units that have compressors using polyolester (POE) oils, due to the hygroscopic nature of the oil. Copper tubing must be refrigeration grade (ACR).
- When using high temperature solders, **always** pass dry nitrogen through the lines to prevent scaling.
- Interconnecting line size should never be based on the lead sizes at the compressor/evaporator section and the condenser section. For proper system operation, they must be sized in accordance with the remote condenser line size table, as shown in Fig. 4 on Page 24. The interconnecting lines **must** be evacuated. Be sure to install appropriate fittings.

Refrigeration Liquid Line – **Split-Systems only** (See Line Size tables in Fig. 4 on Page 26)

1. Liquid lines should be kept as short and direct as possible.
2. Lines should be sized for low pressure drop to prevent liquid flashing. The height of liquid risers must be taken into account.
3. **Do not run liquid lines through heated spaces.** At best, this will result in a loss of subcooling. At worst, the liquid refrigerant may flash.
4. **Do not insulate liquid lines.** Liquid refrigerant moving through the line will normally be warmer than the surrounding air. Uninsulated lines will allow for some heat exchange between the refrigerant and ambient air. This increased subcooling will result in slightly increased capacities.
5. **Brace liquid lines securely to prevent damage to the line from liquid hammer.** Liquid lines are prone to substantial motion when valves are suddenly opened or closed. The bigger and longer the line, the more pronounced the problem. This is caused by the shock of the liquid column impinging on the next closed valve, or on the first bend in the line that it encounters, and is a major cause of joint failure.

Refrigeration Discharge Line – **Split-Systems only** (See Line Size tables in Fig. 4 on Page 26)

1. Discharge lines should be kept as short and direct as possible.
2. Lines should be sized for low-pressure drop in order to minimize the effect of pressure drop on system capacity.
3. These lines should **not** be insulated *except* to prevent injury to personnel who may come in contact with them.
4. Horizontal lines should be pitched downward in the direction of flow to prevent oil from flowing back to the compressor during a off cycle.
5. Vertical lines require a trap at the base of the riser as well as an inverted trap at the top. The inverted trap should be the highest point in the discharge line and should have a access valve installed to allow for purging of non-condensables from the system. For vertical runs greater than 10-12 ft, additional traps should be used at 10-ft. intervals.
6. Systems using unloading compressors may require the use of double risers.
7. Line pulsation is an inherent characteristic in systems utilizing reciprocating compressors. Additional line support may be required to prevent transmission of vibration & movement in the line.
8. An inverted trap of sufficient height or a check valve may be required to prevent liquid migration back to the compressor during off cycles. This can be especially important on units using flooding head pressure controls, due to their larger refrigerant charge.

Wiring

All field wiring must conform to the requirements of the equipment and to all applicable national and local codes.

Main power wires must be kept a minimum of 12 inches away from all low voltage wiring and controls, such as the microprocessor, temperature sensors, and transducer cables. Power wires can create “noise” that will interfere with the operation of the microprocessor and sensors, such as false readings and nuisance trips.

****All Equipment needs to have its own dedicated power Supply**

- Use only copper conductors that are properly sized to handle the load. Always consult the unit's electrical nameplate. Since equipment is continuously being updated, do not rely on catalog information unless it has been verified.
- Always refer to the unit electrical nameplate for sizing conductors, disconnects, and fusing. Units are factory wired so that a single power source can be brought to the unit. However, this may not always be the case with non-standard units. Consult the wiring diagram affixed to the inside of the control panel lid. Additional wiring diagrams are supplied as a separate loose item in the envelope that contained these instructions.
- Electrical connections have been securely tightened at the factory. They may loosen during shipment and again during initial periods of operation. All connections should be checked and tightened as necessary prior to startup and again after the system has been operating for 1 to 2 weeks. To avoid personnel injury, always disconnect power before conducting tightness checks.
- Disconnect switches (fused or non-fused) are optional items when the system is purchased and normally are not factory supplied. They must be field-supplied and field-installed as required by applicable national and local electric codes.

Compressor Oil Charge

- All compressors intended for use with R-134A, R-404A, R-407C, & R-507 are shipped with POE oil.
- For all compressors with an oil sight glass, the proper oil level is between 1/2 to 3/4 up the sightglass.
 - For 8-cylinder compressors, the level should be 1/4 to 1/3 up the sightglass.
- Oil levels should be observed at start-up and when the system is operating. Add or remove oil from the system as necessary to maintain these levels.
- Always remember: *Too much oil is just as detrimental to a system as not enough oil.*

Low Oil Level

In the absence of a visible oil leak, a low oil level generally indicates one or more of the following problems:

1. Oil was not at the proper level to begin with.
2. Refrigerant lines are not properly pitched. This rarely is a problem with factory piping and is usually encountered with field piping on Split-Systems. The usual causes are:
 - a. Failure to pitch piping in direction of flow.
 - b. Excessively large lines which allow refrigerant velocities to drop below the point where oil remains entrained.
 - c. Failure to provide traps in vertical risers
3. Low refrigerant mass flow.
4. A system component such as the suction accumulator having a blocked oil return.
5. Compressor short-cycling.

High Oil Level

Excessively high oil levels are generally caused by one or more of the following:

1. Oil was not at the proper level to begin with.
2. Oil was simply added to the system due to a low sightglass without looking for the cause.
3. A compressor changeout using a compressor with a full oil charge. Replacement compressors generally contain no oil or have a reduced charge.
4. During long off cycles, liquid refrigerant may migrate to the compressor where it can lay in the crankcase. This gives the impression of high oil levels when the compressor is not running. On starting the compressor, this refrigerant will rapidly boil off as evidenced by violent foaming in the sightglass. This in turn may cause tripping of the oil pressure safety switch. A properly working crankcase heater will normally eliminate this problem.

The following oils have been approved by Copeland & Bitzer for use with their compressors:

Polyolester (POE) Oils: Mobile, Emkarate RL 32CF, EAL ARCTIC 22CC, ICI

Leak Testing

Refrigeration Side

Prior to startup, the entire system must be leak tested. Due to their greater sensitivity, electronic leak detectors are recommended. Carefully leak test both factory and field made joints including condenser coils. Although each unit is factory leak tested, joints can loosen and sometimes break during shipment.

As with electrical connections, gasketed and flared joints may loosen after a short running time. Approximately 1 to 2 weeks after placing a system into operation, return and again leak check the various joints. Tighten or repair as necessary.

Chilled Fluid Side

After initially filling the system with water or a water/glycol solution, turn on all pumps and allow the fluid to circulate. The entire system should be checked for leaks, paying special attention to joints and seals. Approximately 1 to 2 weeks after placing a system into operation, return and again leak check the various joints. Tighten or repair as necessary.

Evacuation – Refrigeration Side

Evacuating a system to remove moisture and non-condensable gases is necessary if it has been opened to the atmosphere. With Split-Systems, provisions should be made to evacuate the interconnecting discharge and liquid lines prior to opening the shutoff valves provided in each section.

Non-condensables trapped in the system will increase condensing pressures above what would be normal for a particular operating condition. This causes the system to run inefficiently and may cause nuisance trips on high pressure. Moisture will chemically react with refrigerant and oil in the system, creating acids and sludge, which in turn will corrode the system internally. This problem can be especially severe with POE oils. Proper evacuation will eliminate these problems.

CAUTION: Do not attempt to use the refrigeration compressor to evacuate the system. Do not start the compressor while in a vacuum.

Evacuation:

- Connect a deep vacuum pump to both the high side and low side of the system with copper tube or vacuum hoses.
 - The larger the tube or hose diameter, the better. In no case should the inside diameter of the tube or hose be smaller than the vacuum pumps service port.
 - A vacuum gauge capable of showing pressure in microns must be attached. Ordinary charging manifold gauges are not satisfactory!
 - This gauge should be attached to the system as far from the vacuum pump connections as possible. Some gauges of this type may be damaged if exposed to pressures greater than atmospheric.
 - Be sure that the system pressure is below one atmosphere before exposing the gauge to system pressure.
- Manually open all service valves and solenoids as required. Operate the vacuum pump until a pressure of 500 microns is attained.
- Close the vacuum pump service valves so as to isolate the pump from the refrigeration lines being evacuated and turn it off.
- Perform a vacuum decay test by monitoring system pressure for approximately 1/2 hour. It should not rise more than 250 microns.
 - Rising pressure indicates either a small leak, which was not found during leak testing, or moisture in the system.

Troubleshooting:

If a leak is suspected, it must be found and corrected as indicated under the Leak Testing section above, before proceeding any further. Ultrasonic leak detectors are available which “listen” for the high frequency sound of gas rushing into or out of a system. For small leaks, it is not necessary to repressurize the system with refrigerant.

If moisture in the system is the issue, continued evacuation is necessary. Due to the low boiling point of water at very low pressures, the moisture in the system may freeze, especially when using a pump of excessive capacity. An oversized pump can reduce the system pressure so rapidly that freezing will occur, unless special precautions are taken, such as introducing dry nitrogen into the system to maintain pressure or using sun lamps to maintain temperatures above freezing. Attempting to run the vacuum pump after moisture has frozen will greatly prolong the evacuation process, and can possibly damage the pump.

Refrigerant Charging

Once leak testing and evacuation are complete, refrigerant charging may commence. Always refer to the unit nameplate for the type and amount of refrigerant required.

- *Always use a charging manifold with gauges along with a scale to charge refrigerant into a system.*
- When initially charging a system that is in a vacuum, liquid refrigerant can be added directly into the high side while the compressor is off.
 - As much refrigerant as possible should be charged in this manner, since it is the fastest method available.
 - **Never liquid-charge into the low side without taking special precautions as indicated further in this section.**
- Maximize the amount of refrigerant charged by chilling the receiver (when provided) and warming the refrigerant cylinder:
 - Chill receivers by using either liquid or dry ice packed into an insulating blanket which has been wrapped around the receiver.
 - Warm refrigerant cylinders using sun lamps or a warm water bath. *Do not use a torch or heat gun, since these can cause cylinder pressures to increase significantly in a very short time span.*

CAUTION: Cylinder pressures must be closely monitored whenever a refrigerant cylinder is being heated in ANY manner. Allowing pressures to exceed the cylinder pressure rating may result in the cylinder rupturing, with related injury and/or property damage.

- Once system and tank pressures have equalized, other slower methods must be employed to finish charging the system. The method chosen depends on the refrigerant involved.

“Pure Fluid” Refrigerants & Azeotropic Blends

- Refrigerants that are pure fluids (such as **R-134A**) as well as Azeotropic blends (such as **R-507**) can be vapor-charged into the low side of the system.
- **Never attempt to vapor-charge into the system high side.** This will result in the refrigerant cylinder becoming charged by the system, rather than the other way around. Cylinders can quickly become over-pressurized, causing them to rupture with resultant injury and property damage.

Zeotropic Blends & Near Azeotropic Blends

- Zeotropic blends such as **R-404A** and **R-407C**, and Near-Azeotropic blends (such as **R-502**) should generally not be vapor-charged due to *fractionation* (see below).

What is fractionation? Fractionation is the process where the most volatile component(s) in the blend begin to boil first, thereby leaving higher concentrations of the least volatile component(s) behind. Fractionated blends have a **reduced capacity** and become **less effective** when returned to the system. This does not present a problem if the entire contents of the refrigerant cylinder are to be used, since it allows all of the refrigerant to boil off and return the mixture to its original proportions. **If all the refrigerant in a cylinder is to be used, vapor-charging is permissible**, but it is generally not a good habit for regular unit servicing and proper operation of chiller.

When in doubt as to the type of blend being used, refer to a current pressure-temperature chart. If the saturated temperature column for a particular refrigerant shows distinctly different bubble and dew points, it is either a Zeotrope or Near-Azeotrope.

To avoid the problem of fractionation, Zeotrope or Near-Azeotrope refrigerants should be liquid-charged.

Suggested Method:

1. Liquid-charge into the high side.
2. Start compressor.
3. Using a throttle valve, then begin liquid charging into the low side. This ensures that the liquid flashes to vapor before entering the compressor, preventing liquid slug.

**Pure fluid refrigerants and Azeotropes may also be charged in this manner.*

Fractionation is also a concern with system leaks. The problem is negligible in areas of the system where the refrigerant is in a totally liquid or vapor phase. **However, if the leak occurs in a heat exchanger where phase changes are normally encountered, the problem can be more significant.** As the blend becomes increasingly fractionated, the system performance can be affected to the point where the outlet water (or glycol) temperature cannot be maintained. **Additionally, the effects of fractionation also become more significant with increased refrigerant glide, meaning these problems become more pronounced with Zeotropes than with Near-Azeotropes.** If leaks are small and corrected early, simply topping off the system with refrigerant is acceptable. **On the other hand, with systems having repeated or large leakages, it may be necessary to completely evacuate and recharge.**

Amount of Refrigerant Required

The amount of refrigerant required to charge a system depends on the specific components used in the chiller and the type and combination of head pressure control(s) used. Refer to the engineering documents packaged with your chiller for the capacity and sizes of the components in your chiller.

A head pressure control or condenser fan control alone does not require any additional refrigerant. However, flooding type head pressure controls may require a significant amount of additional refrigerant. The exact amount is dependent on the condenser coil design, as well as the minimum head pressures required for proper thermal expansion valve (TXV) operation. Using both fan controls and flooding type controls in the same system can significantly reduce the amount of additional refrigerant required.

For Split-Systems, the size and length of the liquid line between the (2) sections must be considered. The lbs. of refrigerant contained in liquid lines can be estimated from the following table, which is based on 100 lineal feet of Type “L” copper tube and refrigerant densities corresponding to 90°F saturated liquid.

Table 2. Weight Liquid Refrigerant in Copper Tube

Tube O.D. (in)	3/8	1/2	5/8	7/8	1-1/8	1-3/8	1-5/8
R-134A / R-407C (lbs)	3.9	7.4	11.8	24.4	41.6	63.5	90
R-404A / R-507 (lbs)	3.4	6.4	10.3	21.2	36.1	55	78

Start-Up

General

Once installation is complete, **prior to startup** check the following:

1. All refrigerant and electrical connections must be tight. Tighten all loose wire terminal connections that may have loosened in shipping.
2. Shipping spacers on spring mounted compressors have been removed, the neoprene washers used to properly center the compressor foot on its mounting spring and stud have been properly installed, and the mounting nut & washer is reinstalled so as to allow the compressor to “float.”
3. The compressor oil is at the proper level in the oil sightglass (when provided) for the compressor being used. See “Compressor Oil Charge.”
4. Initial settings of thermostats and pressure controls are at the correct level. All adjustable pressure controls and valves will require a final adjustment with the use of a compatible gauge.
5. Control panel is properly wired and in accord with the unit wiring diagram.
6. Main power wires must be kept at least 12 inches away from microprocessor, as they will create “noise” that can interfere with the operation of the microprocessor and sensors.
7. Verify power supply on site and check the wiring of the control circuit transformer before energizing.
8. Check all three-phase motors for proper rotation.
9. **Confirm that ALL refrigerant ball valves and king valves are opened.**

Compressor Precautions

Care must be taken when initially starting a system or when the system has been off for an extended period. At this time, the compressor may contain liquid refrigerant. Simply starting the system and walking away may result in irreparable compressor damage not covered under warranty. To prevent compressor damage, **one or more of the following steps** may be used:

1. All compressors are supplied with a **crankcase heater. It must be activated for 24 hours prior to starting the compressor.** Be sure to check that the heater is functional. This can be done by simply touching the compressor in the area of the heater. It should feel warm to the touch. This check should be performed shortly after energizing the heater and again prior to starting the compressor. **If the compressor is cold, do not attempt to start it.** Locate the source of the problem, correct it, and wait 24 hours before starting the compressor.
2. Use a “safe” heat source such as a heat lamp on the compressor crankcase for approximately 1/2 hour before start-up. **Never use a torch or heat gun.** They can raise system pressures to dangerous levels in a very short time, resulting in injury to personnel as well as property damage.
3. After following steps 1 and 2 above, you can be relatively certain that no liquid refrigerant is left in the compressor. However, this does not mean that liquid refrigerant is not present elsewhere in the low side. **To avoid compressor damage on start-up:**
 1. **Install pressure gauges.**
 2. **Deactivate the liquid solenoid valve.**
 3. **“Bump” the compressor with the following procedure:**
 - i. **Before running the compressor, ensure that the compressor is not in a vacuum.** Running the compressor in a vacuum can quickly cause it to be overworked and burn out the motor.
 - ii. Using a flathead screwdriver with an insulated handle, “bump” the compressor by pressing the contactor switch for 2 seconds. **Do not repeat.**

This process will rapidly reduce low side pressure, causing any remaining liquid to boil off quickly. After this process is complete, it is usually safe to allow the compressor to run.
4. After starting the compressor, listen for unusual sounds such as knocking, shaking, or rattling. **Should these noises be heard, immediately stop the compressor.** Do not restart until the problem is resolved.

NOTE: While scroll compressors are more tolerant to liquid refrigerant than reciprocating compressors, the above precautions should still be observed to extend compressor lifespan.

- **Rotational direction is very important with three-phase scroll compressors. Running these compressors with reversed rotation will result in damage not covered by warranty.**
- When starting a three-phase scroll compressor, refrigerant pressure gauges **must** be attached to both the high & low pressure ports provided on the system. *With the compressor rotating in the proper direction, system suction pressure should drop and discharge pressure should rise to appropriate levels within a few seconds after the compressor is started.* If this is not the case, the compressor is probably running in reversed rotation. Each chiller is computer tested before it leaves the factory, and all three-phase motors (i.e. pumps and compressors) have been set in the proper phase.

- **Turn off the power at the main disconnect, reverse any two of the three main power leads, and restart.** Observe the suction and discharge pressure gauges to verify that the compressor is rotating correctly. If pressures are still not appropriate, some other problem has developed which must be found and corrected prior to running the system.

Microprocessor Operation (Drake Standard Microprocessor)

- **NOTE: Each chiller is factory-tested on a computer-aided test stand. A copy of the test printout is contained in the installation packet. The controller has been factory-programmed for your specific cooling requirements. The paragraphs below explain how the controller operates, and how to change the setpoints.**
- **Refer to the wiring & piping diagrams supplied with the chiller whilst going through the following procedure.**
- The Drake microprocessor (when provided) is powered by 24 VAC and provides control of up to (2) compressors by monitoring water temperature and refrigerant pressures. Compressor control is accomplished by applying 24 VAC to a motor contactor, which powers on the compressor when pulled.
- Run time control parameters are user-programmable and, once set and saved, are maintained in non-volatile memory. Please refer to the Microprocessor Programming section for more information on this topic. On controllers that include an optional remote display, the system parameters can be directly edited.

When Main power is applied:

- Main power is applied to the controller system transformer, which transmits 24 VAC to the controller and all electrical devices. The controller and pressure transducers are now energized, but all pumps and compressors remain off until the POWER button on the panel is switched ON. A total of (6) red dots will illuminate, one for each LED display.
- When the POWER or System Pump buttons are toggled, the controller will save their status to non-volatile RAM. This means that if power is removed and then re-applied, the microcontroller will restore the status of each button (*i.e. an OFF System Pump button will remain OFF when controller is re-powered*).
- The compressor run times are saved every 12 hours in non-volatile RAM.

Power On: POWER button on controller is pressed and held for 5 seconds (Normal operation):

- All the control LEDs briefly flash starts.
- If so equipped, the secondary compressor will energize based on the second setpoint and differential. The same delays outlined for Compressor #1 will be observed. To equalize compressor run time, periodically the primary and secondary compressor assignments will switch. The corresponding LED will illuminate for the actual compressor in use. Should the setpoints be set such that both compressors could be energized at the same time, a short delay will be imposed on the second compressor to redsh as an indicator test, then the digital displays and the power indicator will illuminate. Any previous alarms are cleared. The upper 3-digit numeric LED will indicate the **inlet** water temperature and the lower numeric LED will indicate the **outlet** water temperature. If the control has not been configured the letters “**CFG**” will appear on the upper LED (This is a factory only function).
- The re-circulation pump is energized. There is no status LED for this pump. Any time the power is on, the re-circulation pump is on.
- If the inlet water temperature is above either setpoint plus differential, cooling will be called. After the compressor delay (30 seconds, fixed) the first compressor will energize. The Compressor 1 “**Cp1**” **green LED** illuminates.
- Hot gas relay valves are energized 60 seconds after the compressuuce power line inrush to the chiller.
- Once the setpoint is achieved or surpassed, the compressor will be de-energized. The hot gas relay will also de-energize, but the re-circulation pump will remain energized. The compressor will be available for another call immediately, but will not engage until after the compressor delay time expires.
- When the inlet water setpoint plus differential is again exceeded, the compressor will again energize per the schedule listed above and the cycle will repeat. Compressors used by Drake are rated for continuous duty and will run continuously if required.

System Pump Control: Momentarily pressing the “System Pump” button energizes the system pump relay. The **green “Sys Pump”** LED illuminates. Momentarily pressing the button again turns it off.

Power Off: Press and hold the POWER button. After holding the POWER button for 5 seconds the compressor(s), the hot gas relays and the re-circulation pump will de-energize. The system pump will also de-energize. All controller LEDs will turn off and display will only show (6) dots, same as after power on.

The pressure transducers will remain powered. The main power disconnect must be used to completely remove control power.

Power Failure: Upon power being restored after a power failure the controller will restart and run with the last known user settings. If the controller fails: For restart, it is recommended to remove power for approximately one minute, then re-apply power.

Alarm Conditions and Indications:

- **Temperature Sensor (tSi / tSo):**

Temp Sensor Operating Range: -40°F to 200°F

- If a temperature sensor transmits an **out-of-range temperature**, the reading will be perceived as a defective sensor, and a temperature sensor alarm will activate.
 - “Err” will begin flashing in the upper numeric LED, while one of the following will be displayed on the bottom numeric LED:
 - “tSi” for the **inlet temperature sensor** OR “tSo” for the **outlet temperature sensor**.
 - The control **will de-energize the compressors and hot gas valves** and the **alarm relay will energize**. **The re-circulation pump remains energized**. The fault is cleared by momentarily pressing the “Power” switch after the error has been resolved. It will not reset automatically.
- **Pressure Sensor (tL1 / tL2 / tH1 / tH2):**

Pressure Sensor Operating Range: 0.5VDC to 4.5VDC.

 - If the **voltage received** from the pressure sensor(s) is **above or below the operating range**, the reading will be perceived as a defective sensor, and the pressure sensor alarm will activate.
 - “Err” will begin flashing in the upper numeric LED while one of the following will be displayed on the bottom numeric LED:
 - “tL1” for **compressor 1 low pressure sensor**, “tL2” for **compressor 2 low pressure sensor**,
 - “tH1” for **compressor 1 high pressure sensor**, and “tH2” for **compressor 2 high pressure sensor**.
 - The **compressor and hot gas valve will be de-energized** and the **alarm relay will energize**.
 - The fault is cleared by momentarily pressing the “Power” switch after the error has been resolved. It will not reset automatically.
 - **High Pressure (Hi Pres):**
 - If the outlet pressure **exceeds the high pressure setpoint**, the **red** High Pressure “**Hi P**” LED will illuminate, the “**Hi Pres**” alarm parameter will begin flashing in the upper numeric LED, and the parameter value will be displayed in the lower numeric LED.
 - The compressor and hot gas valve will be de-energized and the alarm relay will energize. The parameter value will be displayed in the lower numeric LED.
 - The fault is cleared by momentarily pressing the “Power” switch after the pressure is less than the setpoint. Once cleared, the control will attempt to function normally. It will not reset automatically.
 - **Low Pressure:**
 - If the outlet pressure is less than the low pressure setpoint for more than 120 seconds, the **red** Low Pressure “**Lo P**” LED will illuminate, the “**Lo Pres**” alarm parameter will begin flashing in the upper numeric LED, and the parameter value will be displayed in the lower numeric LED.
 - The **compressor will be de-energized** and the **alarm relay will energize**.
 - The fault is cleared by momentarily pressing the “Power” switch after the pressure is greater than the setpoint. Once cleared, the control will attempt to function normally. It will not reset automatically.
 - **High Temperature:**
 - If the outlet water temperature exceeds the setpoint for at least 10 seconds, the “**Hi Temp**” alarm parameter name will flash on the upper numeric LED, **but the control will continue to function normally**.
 - **The alarm relay is not affected by the High Temperature alarm and does not energize.** The parameter value will be displayed in the lower numeric LED.
 - When the outlet water temperature recovers to below the setpoint, the “Hi Temp” LED will turn off. Normal run display will resume.

- **Low Temperature:**
 - If the outlet water temperature is falls below the setpoint, the “**Lo Temp**” alarm parameter name will flash on the upper numeric LED, and the parameter value will be displayed in the lower numeric LED.
 - **The compressor will be de-energized and the alarm relay energizes.**
 - The fault is cleared by momentarily pressing the “**Power**” switch after the temperature is greater than the setpoint. Once cleared, the control will attempt to function normally. It will not reset automatically.
- **Water Flow:**
 - If the water flow drops below the point required to keep the flow switch closed, the “**Lo Flow**” alarm parameter name will flash across both numeric LEDs.
 - The control will **de-energize the compressors and hot gas valves, however the re-circulation pump remains energized.**
 - Once sufficient flow has been restored, control will reset automatically.

Review Mode:

A review (read only) mode is available which will display the program variables and settings. The control will continue to run normally during the review mode. To access review mode press the set button. Then use the UP or DN key to step through each parameter. There are eight (8) additional parameters viewable; “**Hi1**”, “**Hi2**”, “**Lo1**”, “**Lo2**”, “**ait**”, “**aot**” (actual pressure readings) which appear first in the list, and “**Hr1**” and “**Hr2**” (compressor hours) which appear after the “**LtA**” setpoint. There is no “**Upd**” function in review mode. To exit the Review mode, momentarily press the “**Set**” key. There is no timeout to automatically exit the review mode.

NOTE: In the event of an alarm, the Review Mode will terminate and the control and alarm settings will be active.

Programming:

- Press and hold the “**UP**” and “**DN**” switches simultaneously for 7 seconds to enter programming mode from the Run Mode. Control will continue to operate while changes are made using the existing parameters. The parameter name will be displayed on the upper numeric LED and the parameter value will be displayed on the lower numeric LED. Use the **UP/DN** keys to change the value, use the “**SET**” to keep that value and advance to the next parameter. The last parameter is “**Upd**,” which, when the “**SET**” key is pressed, will save the settings to memory and make them the active control parameters. This also exits the programming mode. If no keys are pressed after 30 seconds in any programming display, the programming mode is aborted and any changes are discarded.

The following are the parameters and the order of display:

“ dEG ”	Degrees F or Degrees C
“ tC ”	Select whether inlet or outlet temperature control (limits: IN or OUT)
“ SP1 ”	Temperature setpoint for Compressor 1 (limits: -40 to +120)
“ SP2 ”	Temperature setpoint for Compressor 2 (limits: -40 to +120) (requires dual compressor model)
“ dF1 ”	Temperature differential #1 (limits: 1 to 10)
“ dF2 ”	Temperature differential #2 (limits: 1 to 10) (requires dual compressor model)
“ HP1 ”	High pressure setpoint #1 (limits: 200 to 490 psi)
“ HP2 ”	High pressure setpoint for Compressor 2 (limits: 200 to 490 psi) (requires dual compressor model)
“ LP1 ”	Low pressure setpoint #1 (limits: 1 to 100 psi)
“ LP2 ”	Low pressure setpoint for Compressor 2 (limits: 1 to 100 psi) (requires dual compressor model)
“ HtA ”	High temperature outlet water alarm (limits: max setpoint + max differential +2)
“ LtA ”	Low temperature outlet water alarm (limits: min setpoint – 2)
“ Upd ”	Update settings to permanent memory, exit programming mode to active mode.

NOTE: In the event of an alarm the programming mode will terminate and the control and alarm settings will be active. Any new settings will be discarded.

Initial Setup (Factory Set-up):

- Press and hold the “UP” and “PUMP” switches for more 3 seconds to enter Factory Mode from the Run Mode or Setup Mode. If the control is unconfigured, this mode will appear automatically and the factory default configuration will be loaded.
- The upper display shows “CFG”. Press the “SET” key and the configuration menu will begin. The name of the parameter being set will appear in the upper LED and the value will appear in the lower LED. Use the “UP” and “DN” keys to change the value to the desired setting. Once at the desired setting, press the “SET” key to move to the next parameter. Repeat the sequence to set all parameters. There are extra parameters in the factory menu. The last parameter is “Upd”, which will save the changes when the “SET” key is again pressed. Due to the nature of the possible changes, there is no timeout from this mode. The values will be saved and the control will begin operation using the new parameters after a few seconds. The parameters are listed below:

“dEG”	Degrees F or Degrees C
“CP-”	Number of compressors, 1 or 2
“tC”	Select whether inlet or outlet temperature control (limits: IN or OUT)
“SP1”	Temperature Setpoint #1 (limits: -40 to +120)
“SP2”	Temperature Setpoint #2 (limits: -40 to +120) (requires dual compressor model)
“dF1”	Temperature Differential #1 (limits: 1 to 10)
“dF2”	Temperature Differential #2 (limits: 1 to 10) (requires dual compressor model)
“HP1”	High Pressure setpoint #1 (limits: 200 to 490 psi)
“HP2”	High Pressure setpoint for Compressor 2 (limits: 200 to 490 psi) (requires dual compressor model)
“LP1”	Low Pressure setpoint #1 (limits: 1 to 100 psi)
“LP2”	Low Pressure setpoint for Compressor 2 (limits: 1 to 100 psi) (requires dual compressor model)
“HtA”	High temperature outlet water alarm (limits: max setpoint + max differential +2)
“LtA”	low temperature outlet water alarm (limits: min setpoint – 2)
“Hr1”	Compressor 1 hours (in 100 hr increments), either keep value or reset to zero (toggle)
“Hr2”	Compressor 2 hours (in 100 hr increments), either keep value or reset to zero (toggle, requires dual compressor model)
“Upd”	Update settings to permanent memory, exit programming mode to active mode.

NOTE: Due to the nature of the changes possible in the Factory Mode, the control is taken offline whilst in this mode.

Drake Remote Display Unit Operation:

- The Drake Remote Display Unit (RDU) is connected to the Drake Chiller Controller via a CAT5 patch cable. The cable provides 24VAC power and serial communication to the RDU.
- “STD” or “OPT” modes available.
- RDU mimics all LEDs, displays, and errors on the Drake Chiller Controller
- Independent Review Mode can be used on the RDU, and is the same as the Drake Chiller Controller Review Mode.

Initial Programming -- Remote Display Unit:

1. Set up the Drake Chiller Controller as above.
2. Connect the RDU to the Drake Chiller Controller via a CAT5 patch cable.
3. Power on the Drake Chiller Controller, which in turn will power the RDU.
4. On the RDU, enter Factory Setup Mode by holding “UP” and “PUMP” for at least 3 seconds. The setup screen will request a password to enter into Factory Setup Mode.
5. “PAS” will appear on the upper LED display and “000” on the lower LED display. By pressing the “UP” or “DN” key you will see the first digit on the left increment or decrement. When you are at the desired number, press the “SET” key. A degree symbol will now replace the number you have just entered. Repeat this process to enter the second and third password digits.
6. If you have entered the correct password, you will now be in Factory Setup Mode. If not, “BAD” “PAS” will be displayed and the unit will return to Run Mode. To try again, you must reenter Factory Setup Mode, starting from Step 4.
7. The table below shows the parameters that you will be able to access Factory Setup Mode. The 15th parameter (“rdu”) is only available in Factory Setup Mode of the RDU. All other parameters are the same as a typical Drake Chiller Controller.

“dEG”	Degrees F or Degrees C
“CP-”	Number of compressors, 1 or 2
“tC”	Select whether inlet or outlet temperature control (limits: IN or OUT)
“SP1”	Temperature Setpoint #1 (limits: -40 to +120)
“SP2”	Temperature Setpoint #2 (limits: -40 to +120) (requires dual compressor model)
“dF1”	Temperature Differential #1 (limits: 1 to 10)
“dF2”	Temperature Differential #2 (limits: 1 to 10) (requires dual compressor model)
“HP1”	High Pressure setpoint #1 (limits: 200 to 490 psi)
“HP2”	High Pressure setpoint for Compressor 2 (limits: 200 to 490 psi) (requires dual compressor model)
“LP1”	Low Pressure setpoint #1 (limits: 1 to 100 psi)
“LP2”	Low Pressure setpoint for Compressor 2 (limits: 1 to 100 psi) (requires dual compressor model)
“HtA”	High temperature outlet water alarm (limits: max setpoint + max differential +2)
“LtA”	low temperature outlet water alarm (limits: min setpoint – 2)
“Hr1”	Compressor 1 hours (in 100 hr increments), either keep value or reset to zero (toggle)
“Hr2”	Compressor 2 hours (in 100 hr increments), either keep value or reset to zero (toggle, requires dual compressor model)
“rdu”	Remote Display Unit – “Std” or “Opt” (“Std” is default)
“Upd”	Update settings to permanent memory, exit programming mode to active mode.

RDU – Standard (Std) Mode:

- Only enter Factory Setup Mode if you are authorized and know the password
- Entering Setup Mode is disabled
- Power button’s only function is to clear an error on both the Drake Chiller Controller and RDU, when momentarily pressed
- “SET” button is used to place the remote unit in/out review mode
- “UP” button is used to silence the buzzer for 10 minutes during an alarm.
- “System Pump” button is disabled.

RDU – Operational (Opt) Mode:

- Only enter factory setup if you are authorized and know the password
- Entering Setup Mode is enabled
- Power button is used to power on/off RDU *and* the Drake Chiller Controller. Also clears an **error on both the RDU and Drake Chiller Controller, when momentarily pressed.**
- **“SET” button is used to place the remote unit in/out review mode**
- **“UP” button is used to silence the buzzer for 10 minutes during an alarm.**
- **“System Pump” button is enabled, and will turn the system pump on/off on the chiller controller**

Run Mode:

- While the Drake Chiller Controller is in normally operating Run Mode, the RDU will display a copy of the Controller display, including the status of the Controller’s LEDs (i.e. which LEDs are on/off).

Review Mode:

- While the Drake Chiller Controller is in normal Run Mode (no alarms, not in Setup Mode) a Review Mode is available which will display the program variables and settings of the Drake Chiller Controller. The control will continue to run normally during the Review Mode.
- Use the **“UP” or “DN” key to step through each parameter.**
- To exit the Review mode, momentarily press the **“SET” key.** There is no timeout to automatically exit Review Mode.

NOTE: In the event of an alarm, the Review Mode will terminate and the control and alarm settings will be active.

Offline Mode:


- In the event that the RDU has power, but is not receiving serial information from the Drake Chiller Controller, it will display **“OFF”** on the upper display and **“Lne”** on the lower display. This indicates that the Drake Chiller Controller has power, but is not communicating to the Remote Display Unit (RDU). This is most likely a wiring issue, and should be fixed immediately to restore proper operation.

Alarms:

- Alarms on the Remote Display Unit (RDU) are shown exactly as they are shown on the Drake Chiller Controller.
- The Alarm relay on the Drake Remote Display Unit functions the same the Alarm relay on the Drake Chiller Controller.
- While an alarm is active, the RDU will also sound a buzzer at 50% duration.
 - If the **“UP” key is pressed during this time, the buzzer will be silenced for 10 minutes while still in the same alarm.** If the error still exists after 10 minutes of silence, the buzzer will sound again.
 - If another different alarm occurs within those 10 minutes, the buzzer will also sound again.
 - If applicable to the particular alarm, momentarily pressing the **“Power” key will clear the error and silence the buzzer.**

OPERATIONAL CHECK AFTER INSTALLATION, CHECK ALL OF THESE STEPS

1. **CAUTION (When pumps are provided):** The chilled fluid side of the system must contain either water or a water/glycol solution before turning on any pump. Pumps should not be allowed to “deadhead,” and those using three-phase motors must be checked for proper rotation. Allowing a pump to run dry, deadheaded, or in reverse rotation may all cause damage not covered by warranty.
2. **With the pumps running & all valves open, check the chilled fluid circuit.** Note that the ball valve on the discharge side of the tank recirculation pump has been factory set for the proper evaporator flow rate & the handle removed. **Do not readjust unless otherwise specified by Drake Tech Support or Engineering.**
 1. **First**, bleed the tank using the boiler drain provided (closed-vented tanks only).
 2. **Second**, bleed the chilled fluid lines at their high points.
 3. **Third**, bleed the system’s water flow switch located in the compressor compartment.
 - i. **Air trapped in the flow switch lines will trip the switch and prevent the chiller from operating. This will trip the “Low Flow” alarm on the Drake Chiller Controller.**
3. **Attach thermocouples to the evaporators Entering & Leaving water lines**, and to the suction line, as close to the expansion valve bulb as possible. **Always disconnect electrical power before replacing fuses.** The refrigeration circuit may now be turned on, by replacing the compressor fuses, if they had been removed. Refer to “System Controls, Electrical” for details concerning thermostat adjustments. Be sure that the Compressor Precautions from above have been followed.
4. **Allow the system to operate for 1 – 2 minutes.** Check refrigerant pressures, water temperatures, etc. to ensure that all readings are in line with what could be expected at present water temperatures, ambient temperatures, etc.
 - i) **Keep in mind that pressure-limiting expansion valves are used to limit low side pressures for most chillers, regardless of water temperature.**
 - ii) **Typical Standard Chiller -- Low Side Pressure Limit:** Equivalent of 55°F
 - iii) **Low Temp Operation Chiller – Low Side Pressure Range:** Equivalent of -5° to 0°F.
5. For the evaporator to operate at maximum efficiency, a superheat of 8-20°F at the compressor is required to be verified by the start-up technician, and adjusted if necessary.
6. To ensure that liquid refrigerant does not return to the compressor during the running cycle, maintaining proper superheat at the compressor suction inlet is critical. Drake recommends a maximum of 20°F superheat at the compressor suction inlet, to prevent liquid refrigerant flood-back; this must be verified by the start-up technician and adjusted if necessary.



Adjustment Method:

1. **Measure** the **temperature** and **pressure** 6 inches from the compressor suction valve.
 2. **Convert** the temperature using a **P-T chart.**
 3. **Subtract** this conversion from the measured temperature.
 4. The resulting number is the **superheat** at the compressor.
 5. Check Compressor oil level and stability. If milky or bouncy increase superheat. If clear and stable leave alone or decrease slowly to desired superheat.
- **Check the liquid line sight glass to make sure it is clear with steady liquid.**
 1. **NOTE: A slightly bubbling sightglass does not necessarily mean the system is undercharged.** Take this into account when installing/servicing the unit.
 2. Small amounts of bubbling may result from the following:
 3. Cool weather operation without head pressure controls
 4. Locating the sightglass close to the condenser outlet.

- **Check status of moisture indicator:**
 - **GREEN** – Normal Operation
 - **Light Red** – Small amount of moisture in the system. This can usually be removed by the filter drier & does not necessarily indicate a serious problem. The indicator should be monitored over the next few days & corrective action taken as required.
 - **Bright Yellow** – Large amounts of moisture in the system. Can be indicative of a serious problem. Do not rely on the filter drier under these circumstances & do not run the refrigeration equipment until the problem is resolved.
- **Ensure that the system recirculation pump has proper flow.** All systems require a system circulation pump to move the chilled fluid between the chiller & whatever machinery, process etc. is being cooled. Care must be taken to ensure that fluid flow rates are in line with the requirements of the system being cooled. Flow meters and/or regulators may be required.
 - **Flow rates can be adjusted using ball valves on the discharge side of the pump. Never adjust flow from the intake side of a pump.** *Always remember that if the machinery, process etc. is not being properly cooled, the problem is normally flow rates that are either too high or too low.*
 - **Do NOT attempt to solve the problem by simply lowering the thermostat setting.** This is normally not a solution & may damage the system.
- **Chillers using integral recirculation tanks:** The ball valve installed on the discharge side of the tank recirculation pump is factory-set to maintain an approximate 5°F TD across the evaporator. The handle is then removed & wrapped to the valve with zip ties. Under most circumstances, no readjustment is necessary.
- **Systems using a chilled fluid recirculation tank:** It may be necessary to leave the system pump off until the fluid inside the tank reaches the desired temperature.

Check with Gauge or Thermometer

The following adjustable controls & valves must be checked with an appropriate gauge and/or thermometer. Many are optional items, which may not be included in your system. *Refer to System Controls -- Electrical & System Controls – Mechanical for description & settings.*

1. **Condenser Fan Control**
 2. **Evaporator Heat Tape Freeze Protection Thermostat**
 3. **Discharge Bypass Valve**
 4. **Head Pressure Control Valve**
 5. **Thermostatic Expansion Valve**
 6. **Water Regulating Valve**
 7. **Compressor Unloading Pressure Switch**
- **Do not leave the system unattended until normal operating conditions have been reached & the compressor oil level has been adjusted to maintain the proper level.**
 - **Once the system has operated for 2 or 3 hours without any sign of problems, it may be left operating overnight. The following day, recheck the system as follows:**
 1. **Check both high & low side pressures.** If they are not within appropriate ranges, determine the cause & correct.
 2. **Check sightglass** for signs that additional refrigerant is required. Before adding any refrigerant, leak check the entire system correcting any leaks that may be found.
 3. **Check compressor oil level** where appropriate. Add or remove oil as necessary.
 4. **Check evaporator superheat** and readjust expansion valve as required.
 5. **Check voltage & amperage** at the compressor power terminals. **Voltage must be within ±10% of the nominal as indicated on the unit nameplate.** If it is outside of this limit, contact the local power company. If amperage is excessive, the cause must be determined & corrective action taken. With a three-phase line, the load must be balanced at each phase.
 6. **Check all safety & operating controller** settings in the review mode for proper settings & operation.
 7. **Check all head pressure controls** for proper operation. This may not be possible during warm weather & it will be necessary to wait until the ambient temperature falls below 70°F.

System Controls, Electrical

One or more wiring diagrams are supplied on the inside of the control panel lid, as well as in the envelope that contained these instructions. These should be referred to while reading these instructions.

Catalog-listed chillers can be built for operation on the following electric services. Not all models however are available for every electric service shown below.

Designation	Electric Service (V/Phase/Hz)	Designation	Electric Service (V/Phase/Hz)
S2	208-230/1/60	S6	220/1/50
T3	208-230/3/60	T7	200/3/50
T4	460/3/60	T9	380/3/50
T5	575/3/60		

- **Regardless of which electric service is ordered, the system control circuit operates on 24 VAC.** This is accomplished through a “step-down” transformer located in the control panel.
- All parts mounted in the control panel are clearly labeled. Unless otherwise shown on the wiring diagram, **all control panels contain a main terminal block intended for single point electrical connection.**
- **Compressor Unloading Pressure Switch:** Optional component, normally mounted in the compressor compartment.
 - Senses compressor suction pressure & will deactivate banks of compressor cylinders in response to a drop in suction pressure, due to low load conditions.
- **Condenser Fan Control, Ambient Temperature Switch:** Optional component, normally mounted on the back of the control panel in the compressor compartment.
 - Senses ambient temperature and will de-energize fan motor(s) when the temperature drops below the control setting. Motor(s) will be re-energized when ambient temperature rises to a predetermined level.
- **Condenser Fan Control, Variable Speed:** Optional component normally mounted on the back of the control panel in the compressor compartment. The feeler bulb is connected to the liquid line piping at the outlet of the condenser coil. It will begin to modulate fan speed when the sensed temperature drops to 100°F & will proportionally reduce fan speed until the temperature reaches 70°F at which point power to the motor is cut off. As the temperature rises, the motor will restart at full speed and then modulate to the appropriate RPM. Caution – the power wiring to the fan motor(s) must be derived from the same two-phase lines as those, which are wired to the primary side of the control circuit transformer.
- **Fusing:** Condenser fan motor(s), as well as the control circuit, are fused using **class-“R” dual-element time delay cartridge fuses**. Replacing these with non-time-delay fuses of the same amperage rating may result in nuisance trips. Non-time-delay fuses with higher amperage ratings may not fit in the fuse block provided.
- **Heat Tape Freeze Protection:** Optional item, consisting of low wattage (5 Watts/ft) heat tape wrapped around the heat exchanger below the insulation, and operated by a thermostat wired to close on temperature drop. The thermostat bulb is strapped to the bottom of the water line leaving the heat exchanger. Typical setting for the thermostat: 35°F.
- **Indicator lights (with or without dry contacts):** Optional component(s). Indicator lights are externally visible and normally mounted adjacent to the control panel.
 - **GREEN** – Normal Operation
 - **RED** – Indicates Problem!
 - Wiring for the indicators varies depending on their use. Refer to wiring diagrams.
 - If dry contacts are ordered with any indicator, a DPDT relay is included in the control panel. The relay coil is wired in parallel with it corresponding indicator. The controller has relay terminals that can be connected to a remote audible or visual alarm, should the controller fault and shut down the chiller. Reference the wiring diagram for the location of these terminals for field connection.

- **Switch, Disconnect:** *(Optional Component)*
 - **This is a safety device and should not be used as an on/off switch.** Throwing this switch to the off position will remove all power from the system, including the compressor crankcase heater. *This may result in irreparable damage to the compressor when restarting.* See “Start-Up.”
 - *It is generally the responsibility of the installer to provide and mount a fused or non-fused disconnect switch, as per national and local electric codes.*

- **Switch, Oil Pressure:**
 - A safety device that senses compressor crankcase pressure. It is used with all compressors which have a positive displacement oil pump and is located in the compressor compartment. These switches contain a non-adjustable timing circuit, which allows the crankcase pressure to come up to a predetermined minimum before shutting down the compressor. The length of the time delay is dependent on the particular compressor.

- **Microprocessor controller:**
 - Temperature controller mounted on the chiller panel, which senses the temperature of the chilled fluid returning to the chiller. Its range is -30° to +220°F, with an adjustable differential of 1° to 30°F.
 - **When using plain water, never set the thermostat lower than +42°F unless the chiller has been specifically built to operate at a lower temperature.** Failure to do this may result in heat exchanger freeze-up and rupture, which in turn will destroy the refrigeration circuit. **This type of failure will void any warranty on the equipment.**
 - When colder temperatures are required, a glycol/water solution can be used. The thermostat can then be lowered below +42°F. The lowest setting is dependent on the type and concentration of glycol used.

- **Transformer(s):**
 - The control circuit transformer is used to step down the system voltage to 24 VAC used to power the control circuit.
 - Additional transformers may be used to power selected components as shown on the wiring diagram. On systems intended for use on 208-230V electric service, the transformer leaves the factory wired for 230V on the Primary side.
 - Some transformers must be rewired when used on a 208V network. Always check the wiring of the transformer primary circuit before energizing.

- **Water Flow Switch:**
 - A safety device used to sense flow through the evaporator. It is a heat dissipation flow sensor typically mounted to the water inlet of the evaporator and wired to the electrical control box.
 - **If flow rates drop for any reason, the flow switch will shut down the unit completely until flow is restored.**

System Controls -- Mechanical

One or more piping diagrams are supplied in the envelope that contained these instructions. These should be referred to while reading these instructions.

- **Discharge Bypass Valve:** A modulating control valve which opens on a decrease in suction pressure, and can be set to automatically maintain a desired minimum evaporating pressure regardless of the evaporator load.
 - **Valves typically used have an adjustment range of 0 – 80 PSIG.** Other ranges are available and may be used depending on application. The valve is factory-set to maintain a minimum evaporating temperature of 34°F for most applications. **Do not reset to a lower pressure when chilling ordinary water unless specially designed heat exchangers are employed.**
 - For applications using glycol solutions, this valve can be safely reset to maintain a lower minimum pressure. The exact setting will be dependent on the type and concentration of glycol used. To reset the valve, the following procedure should be followed:
 1. Remove the cap and insert a 5/16" allen wrench into the adjusting screw. Turning this screw clockwise will increase the setting and counter-clockwise will lower the setting.
 2. A high evaporator load is initially required to raise the evaporator pressure above the desired setting.
 3. Slowly decrease the load until the regulating valve begins to open. This will be indicated by a hissing sound and/or an accompanying temperature rise at the outlet.
 4. Note the evaporator pressure when the valve opens. This is the current pressure setting of the valve.
 5. Turn the adjusting screw as required and repeat steps 2 through 4 to determine the new valve setting.
 6. Repeat this procedure until the valve is set at the proper pressure for the service required.
- **Head Pressure Control Valve – Adjustable:** Systems with these valve(s) use a combination of Sporlan ORD/ORI valves.
 - The ORI valve is adjustable over a range and is located in the liquid line between the condenser and receiver. Due to its wide adjusting range, it can be used with most commonly used refrigerants. The valve will throttle and restrict the flow of liquid refrigerant from the condenser. Adjusting the valve is done by removing the cover over the adjusting screw and turning it clockwise to raise pressure and counter-clockwise to reduce pressure.
 - The ORD valve is a non-adjustable pressure differential check valve located in a bypass line between the systems discharge line and the receiver inlet. As the ORI valve restricts flow from the condenser, it creates a pressure differential across the ORD valve. This allows the ORD valve to bypass hot gas directly into the receiver, warming the liquid refrigerant and thereby maintaining a constant pressure at the expansion valve.
- **Head Pressure Control Valve – Non-adjustable:** Systems with these valve(s) use a Sporlan OROA valve, which is factory set to maintain a set discharge pressure depending on the refrigerant.
 - R-404A, R-407C, R-507: 225 PSIG discharge pressure
 - R-134: 100 PSIG discharge pressure.
- **Solenoid, Liquid:** Electrically operated (energize to open) valve used to control the flow of **liquid refrigerant to the expansion valve.**
- **Solenoid, Hot Gas:** Electrically operated (energize to open) valve used to control the flow of **discharge gas to the discharge bypass valve.**
- **Thermostatic Expansion Valve:** A modulating valve used to meter refrigerant into the evaporator in response to the imposed load. It does this by maintaining a constant superheat of the refrigerant vapor at the suction outlet of the evaporator. The lower the superheat, the more efficiently the evaporator is operating. **From a practical standpoint, Drake recommends a superheat of 8° - 10°F at the evaporator.**
 - To adjust superheat, remove nut covering the adjusting stem. Turning the stem clockwise will increase superheat and slightly decrease the valve capacity. Turning the stem counter-clockwise will decrease superheat and slightly increase the valve capacity. Keep in mind that superheat cannot be adjusted when the system is operating well above setpoint.
- **Water Regulating Valve:** An optional modulating type valve used with water-cooled condensers to maintain a constant head pressure.
 - The valve senses discharge pressure and modulates the flow of water through the condenser in response to this pressure. Turning the adjusting stem on top of the valve will increase or decrease the systems discharge pressure.
- **All water regulating valves should be installed on the leaving fluid condenser outlet.**

Warranty Repairs

All in-warranty repairs must be performed by competent refrigeration mechanics that are familiar with this type of equipment. Prior to the commencement of the work, factory authorization is required. Billing for parts and labor will not be considered without this authorization.

See Terms and Conditions of Sales on next page.

TERMS AND CONDITIONS OF SALE

ORDER PROCEDURES- All equipment-requiring options are manufactured to order after receipt of customer purchase order. Some of the standard units are stocked and available for shipping generally within three working days.

DELIVERY REQUIREMENTS- Indicate at time order is placed.

STANDARD DELIVERY- Manufactured to order, approximately in 2-3 weeks (Weeks to ship will vary due to workload,) Shipping inquiries will be estimated to the "week ending."

EXTENDED DELIVERY- manufactured to order and shipped as per requested, when applicable, within the weeks required.

PRIORITY DELIVERY- Manufactured to order in 3-10 working days. Must have factory authorization in advance.

QUOTATIONS- All quotations in writing automatically expire thirty (30) days from the date of quotation and may be terminated by notice within that period. All oral quotations automatically expire five (5) days from date of quotation and are subject to change without notice. All orders are subject to approval at the factory by and authorized employee of the Seller. Orders are accepted under the Seller's terms, conditions, and price information as of the date of the Seller's factory acknowledgment of the order. Orders, originally entered, and then "held" for future release will be subjected to the Seller's terms, conditions, and price information as of the date Buyer's release is accepted by the Seller.

CANCELLATIONS- The buyer may not cancel an order except upon a verbal notice followed by a written notice and on payment of a reasonable and proper sum to compensate for expenses incurred in the engineering and manufacturing of said order to the date of cancellation.

TERMS OF PAYMENT- Credit is a privilege and all orders will be shipped C.O.D. unless prior arrangements have been made with the credit department. Direct all inquiries for information to the credit manager. All goods are sold FOB factory suitably packed or crated for domestic shipment. Export shipments are subject to additional packing charge.

Terms to buyers of satisfactory credit are-NET 30 DAYS FROM DATE OF INVOICE. NO CASH DISCOUNT ALLOWED. No shipments for accounts 45 days outstanding. Shipments made only after receipt of payment on all outstanding invoices. For special orders, a down payment or deposit may be required.

SALES TAXES- Sales or use taxes required by law to be collected or paid by seller be in addition to prices quoted unless appropriate tax exemption certificate is furnished.

SHIPPING- All shipments will be forwarded FOB, PHILADELPHIA, PA.

- 1.) Prepaid only when open accounts terms are applicable to shipment.
- 2.) Collect on all other accounts.
- 3.) Insurance will be automatically added to UPS shipped valued in excess of \$100.00
- 4.) All COD shipment will include the appropriate COD charges, when applicable.

DAMAGED FREIGHT- The consignee (buyer) is responsible for filing a freight claim with the delivering carrier should freight damages occur. Damages in shipment are not considered the responsibility of the factory. An inspection should be made at the time of delivery for any visible sign of mishandling by the carrier. Damages MUST be noted on the delivery receipt and a request for an inspection should be made immediately by the freight company adjuster. All packaging MUST be retained for the INSPECTION of the carrier or claim may be denied.

RETURNED GOODS- All returned goods must be authorized in advance. Only new and unused equipment will be considered for return. All items must be sent freight prepaid and include a packing slip. Equipment built to order is not subject to return for credit. Items returned that are inspected and found to be "OK" will be subject to a 25% restocking charge. Goods must be securely packed to arrive at the factory without damage. Any cost incurred by the factory to put equipment in first class condition will be charged to the buyer.

IN WARRANTY SERVICE PARTS- In warranty service parts will be invoiced pending receipt of the replaced parts previously authorized for return. After inspection of the replaced part at the factory, credit will be issued against the replacement parts providing the part was returned freight prepaid and that the part was free from abuse or misuse.

EQUIPMENT PARTS WARRANTY-DRAKE REFRIGERATION, INC. WARRANTS TO THE ORIGINAL OWNER OF THE UNIT THAT THE EQUIPMENT WILL BE FREE FROM DEFECTS IN MATERIAL AND WORKMANSHIP FOR A PERIOD OF ONE YEAR FROM THE EFFECTIVE DATE OF THE WARRANTY.

The effective date of this warranty is thirty days after shipment from the factory. The company's obligation under this warranty is limited to the repair or replacement, at its factory, of any part that shows evidence of being defective in material and workmanship and are deemed so by Drake Refrigeration, Inc., during the one year period. No obligation for labor required to replace the defective parts not for freight or Drake Refrigeration, Inc assumes mailing costs to return or to secure the part.

THE COMPRESSOR ONLY WILL BE WARRANTED FOR AN ADDITIONAL FOUR YEARS (TOTAL FIVE YEARS) FROM THE EFFECTIVE DATE OF THE WARRANTY PROVIDED THE EXTENDED WARRANTY IS PURCHASED WITHIN THIRTY DAYS FROM THE EFFECTIVE DATE. The compressor warranty obligates Drake Refrigeration, Inc., to replace FOB the factory, the compressor with a comparable compressor with equal capacity, free of charge. Drake Refrigeration, Inc. assumes no responsibility for refrigerant accessories, labor, or freight to or from the factory. Defective parts will be replaced provided notice of such defect was given by the original owner within the warranty period. Drake Refrigeration, Inc. reserves the right to replace in warranty defective parts from its factory. The warranty does not cover the cost to parts substituted by field service for original equipment parts not authorized by Drake Refrigeration, Inc. Any unauthorized substitution voids the warranty.

THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES. IN NO CASE WILL ANY CLAIM FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES BE APPROVED. THIS WARRANTY DOES NOT APPLY TO THE UNIT OR ANY PART THEREOF WHICH HAS BEEN SUBJECT TO DAMAGE DUE TO TRANSPORTATION,

Pipe Sizing




Fig. 1 Friction Loss for Water in Copper Steel Pipe (Schedule 40)




Fig. 2 Friction Loss for Water in Copper Tubing (Types K, L, M)




Fig. 3 Friction Loss for Water in Plastic Pipe (Schedule 80)

RECOMMENDED REMOTE CONDENSER LINE SIZES

Net Evaporator Capacity BTUs	Total Equivalent Length FEET	R-134a		R-407		R507 & R-404A	
		Discharge Line (O.D.)	Liquid Line (O.D.)	Discharge Line (O.D.)	Liquid Line (O.D.)	Discharge Line (O.D.)	Liquid Line (O.D.)
3000	50	3/8	3/8	3/8	3/8	3/8	3/8
	100	1/2	3/8	3/8	3/8	3/8	3/8
6000	50	1/2	3/8	3/8	3/8	1/2	3/8
	100	1/2	3/8	1/2	3/8	1/2	3/8
9000	50	5/8	3/8	1/2	3/8	1/2	3/8
	100	5/8	3/8	1/2	3/8	5/8	3/8
12000	50	5/8	3/8	1/2	3/8	1/2	3/8
	100	7/8	3/8	5/8	3/8	5/8	3/8
18000	50	7/8	3/8	1/2	3/8	5/8	3/8
	100	7/8	1/2	5/8	3/8	5/8	1/2
24000	50	7/8	1/2	5/8	3/8	7/8	3/8
	100	7/8	1/2	5/8	1/2	7/8	1/2
36000	50	7/8	1/2	7/8	1/2	7/8	1/2
	100	1 1/8	5/8	7/8	1/2	7/8	1/2
48000	50	1 1/8	1/2	7/8	1/2	7/8	1/2
	100	1 1/8	5/8	7/8	1/2	1 1/8	5/8
60000	50	1 1/8	1/2	7/8	1/2	7/8	1/2
	100	1 3/8	5/8	7/8	5/8	1 1/8	5/8
72000	50	1 1/8	5/8	7/8	1/2	1 1/8	5/8
	100	1 3/8	7/8	1 1/8	5/8	1 1/8	5/8
90000	50	1 3/8	5/8	7/8	5/8	1 1/8	5/8
	100	1 3/8	7/8	1 1/8	5/8	1 3/8	7/8
120000	50	1 3/8	7/8	1 1/8	5/8	1 1/8	5/8
	100	1 5/8	7/8	1 1/8	7/8	1 3/8	7/8
180000	50	1 5/8	7/8	1 3/8	7/8	1 3/8	7/8
	100	2 1/8	1 1/8	1 3/8	7/8	1 5/8	7/8
240000	50	1 5/8	7/8	1 5/8	7/8	1 5/8	7/8
	100	2 1/8	1 1/8	1 5/8	7/8	1 5/8	1 1/8
300000	50	2 1/8	1 1/8	1 5/8	7/8	1 5/8	1 1/8
	100	2 1/8	1 1/8	1 5/8	1 1/8	2 1/8	1 1/8
360000	50	2 1/8	1 1/8	1 5/8	7/8	2 1/8	1 1/8
	100	2 5/8	1 3/8	2 1/8	1 1/8	2 1/8	1 3/8
480000	50	2 1/8	1 1/8	2 1/8	1 1/8	2 1/8	1 1/8
	100	2 5/8	1 3/8	2 1/8	1 1/8	2 1/8	1 3/8
600000	50	2 5/8	1 3/8	2 1/8	1 1/8	2 1/8	1 3/8
	100	3 1/8	1 5/8	2 1/8	1 3/8	2 5/8	1 5/8
720000	50	2 5/8	1 3/8	2 1/8	1 3/8	2 1/8	1 5/8
	100	3 1/8	1 5/8	2 5/8	1 3/8	2 5/8	1 5/8
840000	50	2 5/8	1 3/8	2 1/8	1 3/8	2 5/8	1 5/8
	100	3 1/8	1 5/8	2 5/8	1 5/8	2 5/8	2 1/8
960000	50	3 1/8	1 3/8	2 5/8	1 3/8	2 5/8	1 5/8
	100	3 1/8	2 1/8	2 5/8	1 5/8	3 1/8	2 1/8
1080000	50	3 1/8	1 5/8	2 5/8	1 3/8	2 5/8	2 1/8
	100	3 5/8	2 1/8	2 5/8	1 5/8	3 1/8	2 1/8
1200000	50	3 1/8	1 5/8	2 5/8	1 5/8	2 5/8	2 1/8
	100	3 5/8	2 1/8	3 1/8	1 5/8	3 1/8	2 1/8
1440000	50	3 1/8	1 5/8	2 5/8	1 5/8	3 1/8	2 1/8
	100	3 5/8	2 1/8	3 1/8	2 1/8	3 5/8	2 5/8
1680000	50	3 5/8	2 1/8	2 5/8	1 5/8	3 1/8	2 1/8
	100	4 1/8	2 1/8	3 1/8	2 1/8	3 5/8	2 5/8

Fig. 4 Remote Condenser Line Sizes



Drake Refrigeration Chiller Preventative Maintenance Schedule

Type of PM: Quarterly: _____ Annual: _____

Site or Building Name: _____

Technician Name: _____ Date: _____

Chiller Model #: _____ Chiller Serial #: _____

	Initial	Quarterly	Annually
1. Review Chiller Logs		x	
2. Clean Condenser Coils-Fin			x
3. Flush Evaporator			x
4. Flush Condenser-Coaxial			x
5. Test Compressor Oil			x
6a. Change Compressor Oil, Recips			x
6b. Change Compressor Oil, Scroll			x
6c. Change Compressor Oil, Screw			x
7. Check Oil Filters		x	
8. Change Oil Filters			x
9. Check Y-Strainers		x	
10. Check Pump Gaskets/Seals		x	
11. Check For Leaks		x	
12. Tighten All Electric		x	
13. Check Overloads		x	
14. Check Contactors		x	
15. Check VFD'S		x	
16. Check Chiller Operation		x	
17. Complete PM Checklist		x	



Drake Refrigeration Inc. Warranty Activation Form

Issue Date
2014
Supersedes
8-1-00

File Name
Wa.form.
Rev.2

Schedule Type: Drake Chiller start-up & pm checklist

Page: 1 of 3

Start Up/PM Date:			
Site Name:		Site Contact:	
Address:		Phone Number:	
City:	State:	Zip:	Email Address:
Manufacturer:	Drake Refrigeration Inc	Service Company Name:	
Model #:		Service Company Phone:	
Serial #:		Startup Technician:	
Seg. # .			

Visual Inspection

- Inspect incoming voltage matches nameplate voltage, and chiller disconnect per local codes.**
- Inspect installation of equipment mounting, piping, and wiring for completion.
- Inspect chiller location is **free from overhangs and at least 3 feet from any wall or fence.**
- Inspect chiller fluid level is full and free of air.
- Inspect chiller piping and pump housing for any fluid leaks.
(Slight seal leak may occur until pump seal burn in time is complete.)
- Tighten all Rotolock Valves, Schrader valve cores, and Liquid line solenoid body.
- Backseat receiver rotolock valves to release the refrigerant into the system. (If applicable)
- Tighten receiver valve packing nut (if applicable)
- Leak check the refrigerant circuit with an electronic leak detector.
- Inspect chiller name plate voltage matches the voltage supplied to the chiller.
- Tighten all electrical connections in the control panel, microprocessor and other controls.
- Inspect that a filter or Y strainer is installed in the return line of the chiller. Note if not installed.
- Measure the glycol freeze point and log into the chart below. (If applicable)

Chiller Operation

- Refer to the chiller operation manual page 11 to start the chiller.
- Inspect compressor rotation.
- Inspect chiller pump rotation.
- Press the Sys pump button to turn on the system pump. (If applicable)
- Inspect system pump rotation. (If applicable)
- Inspect chiller pump overload setting. (This should match the SFA rating on the pump label)
- Inspect system pump overload setting. (This should match the SFA rating on the pump label)
- Inspect controller set points.
- Inspect and test Flow differential pressure switch for proper operation (adjust if necessary)
- Adjust flow of glycol loop using ball valve to verify a 10F delta "T" on microprocessor display (**Non Tank Units**).
- Inspect Condenser fan operation. (if applicable)
- Inspect Condenser water regulation valve operation. (if applicable)
- Inspect Fan Cycle setting at 70°F. (if applicable)
- Install service gauge set and inspect microprocessor pressure readings. (Microprocessor pressures reasonably match technicians gauge set)
- Inspect indoor remote display panel operation. (If applicable)

Completion Date:	Service Provider: (1)	Material/tool reference
------------------	--------------------------	-------------------------



Drake Refrigeration Inc. Warranty Activation Form

Issue Date
2014
Supersedes
8-1-00

File Name
Wa.form.
Rev.2

Schedule Type: Drake Chiller start-up & pm checklist

Page: 2 of 3

- Motors, Elements**
Complete log sheet
- Compressors**
Complete compressor log sheet

- Microprocessor Setting**
Complete microprocessor table

- Final checklist**
Remove all tools and debris from the equipment.
- Replace all service caps and tighten.
- Replace Receiver valve stem caps and tighten. (If applicable)
- Replace all chiller manuals and documentation into the electrical panel.
- Install & secure all access panels and hardware.
- Review start up documents with the customer
- Give a copy of the start up documents to the customer
- Fax or email a copy of the start up documents to Drake
(215) 638-5518 or tbartlett@drakechillers.com

Log Sheet (Motors, Elements, etc.)

Motor/Element Name	HP	Amp Readings				Voltage Readings		
		L1	L2	L3	*NP	L1	L2	L3
Compressor								=To Ground
Condenser fan #1								=Between lines
Condenser Fan #2								
Chiller glycol pump								
Indoor water Pump								
Receiver Heater								
Liquid Solenoid								

*NP=Name Plate

Compressor Log Sheet

Comp #	Suct Press	Disch Press	Super Heat	Oil Level	Outdoor Ambient Temp F.	LWT. °F	EWT. °F	LP Cut	HP Cut
1									
2									
3									

LWT= Leaving Water temp / EWT= Entering LP-Test low pressure cutout HP-Test high pressure cutout
Heat Ops-Test crankcase heater operation Unload Ops-Test unloader operation

Completion Date:	Service Provider: (1)	Material/tool reference
------------------	--------------------------	-------------------------



Drake Refrigeration Inc.
Warranty Activation Form

Issue Date
 2014
 Supersedes
 8-1-00

File Name
 Wa.form.
 Rev.2

Schedule Type: Drake Chiller start-up & pm checklist

Page: 3 of 3

Glycol Freeze Point :
Micro Flash Version : (this will be displayed at power up)

Microprocessor Table (for settings)

<i>item</i>	Setting	<i>item</i>	Setting
dEG		TC	
CP			
SP1		SP2	
DF1		DF2	
HP1		HP2	
LP1		LP2	
HTA		LTA	
HR1		HR2	

Visit Notes

Completion Date:	Service Provider: (1)	Material/tool reference
------------------	--------------------------	-------------------------



Drake Refrigeration Inc. MCS Warranty Activation Form

Issue Date
3-21-12
Supersedes
8-1-00

File Name
3T.
ACTIVATION.
FORM

Schedule Type: Drake Chiller start-up & pm checklist

Page: 1 of 6

Start Up/PM Date:			
Site Name:		Site Contact:	
Address:		Phone Number:	
City:	State:	Zip:	Email Address:
Manufacturer:	Drake Refrigeration Inc	Service Company Name:	
Model #:		Service Company Phone:	
Serial #:		Startup Technician:	
Seg. # .			

Visual Inspection

- Inspect incoming voltage matches nameplate voltage, and chiller disconnect per national and local codes.**
- Confirm that chiller has power supplied for 24 hours and the disconnect switch is turned ON.
- Inspect installation of equipment mounting, piping, and wiring for completion.
- Inspect chiller location is **free from overhangs and at least 3 feet from any wall or fence.**
- Inspect chiller fluid level is full and free of air.
- Inspect distilled water loop is full of fluid. **If Applicable. N/A if not**
- On indoor heat exchanger inspect disconnect is in OFF position. **If Applicable. N/A if not**
- Inspect chiller piping and pump housing for any fluid leaks.
(Slight seal leak may occur until pump seal burn in time is complete.)
- Tighten all Schrader valve cores and liquid line solenoid bodies.
- Open receiver ball valves to release the refrigerant into the system. **If Applicable. N/A if not.**
- Tighten receiver valve packing nut **If Applicable. N/A if not.**
- Leak check the refrigerant circuit with an electronic leak detector.
- Tighten all electrical connections in the control panel, microprocessor and other controls.
- Measure the glycol freeze point and log into the chart below.

The Chiller can be started via Keypad or Laptop. If using Laptop proceed to next section

Chiller Operation (Via Keypad)

- Refer to the Magnum chiller manuals for Sequence of Operation and Magnum Keypad display
- Go to the Password tab and enter the four digit password for factory clearance
(Call Drake Tech Support for this password 215-638-5515)
- Confirm that all output relays are in the *MANOFF* position via the OUTPUT tab
Use Keypad display manual page 6 #4.3 for guidance
- Go through Set Points option and confirm all set points match the form attached, then initial form.**
- Inspect pump overload settings. (This should match the SFA rating on the pump labels)
- Confirm the process source is capable of providing a load to the chiller.
- Go to the Outputs tab and turn the glycol pump to the *Auto* position. Confirm the phase and proper rotation (Zip-Tie use is recommended).
- Go to the Outputs tab and turn the Distilled water pump to the *Auto* position. Confirm disconnect on heat exchanger is in *ON* position. Confirm the phase and proper rotation (Zip-Tie is recommended).
- Allow the pumps to run and allow the load to bring up 'Chilled Water Out' up to 75°F.
Monitor this via Inputs tab (Keypad Manual page 6 #4.3)

Completion Date:	Service Provider: (1)	Material/tool reference
------------------	--------------------------	-------------------------



Drake Refrigeration Inc. MCS Warranty Activation Form

Issue Date
3-21-12
Supersedes
8-1-00

File Name
3T.
ACTIVATION.
FORM

Schedule Type: Drake Chiller start-up & pm checklist

Page: 2 of 6

- From Outputs tab turn the liquid line solenoid 1 (LLS 1), compressor 1 (COMP 1), condenser fan motor 1 (COND 1), condenser fan motor 2 (COND 2), receiver heater 1 (REC HTR 1), receiver heater 2 (REC HTR 2) to *AUTO*
- Any questions at this point call Drake Tech Support 215-638-5515
- Check compressor rotation
- Fill out Log Sheets-Motor chart and Pressure/Temperature chart**
- Inspect Condenser fan operation. Check phase (if applicable) and motor rotation if 3 phase power.
- Inspect variable fan speed control is set for 2 clicks from max for Cut out speed and Hard start
- Inspect pressure fan speed control settings to maintain min design head pressure of 235-250 psi.
- Setup the Ord/Ori Valve to maintain a minimum operating discharge pressure with all fans running. 235-240 psi for R407C and 250 psi for R404A
- From Output tab turn LLS1 and COMP 1 from *AUTO* to *MANOFF*
- Allow pumps to continue to run until the chilled water out is up to 50-75°F again.
- From Outputs tab turn LLS 2 to *Auto* and Comp 2 to *MANON*
- Complete the Log sheets**
- Turn Outputs from *MANON* to *AUTO* and confirm everything is in *AUTO*.
- Inspect indoor remote display panel operation.

- Chiller Operation (Via Laptop)**
- Bring Windows based computer with the latest version of MCS Connect downloaded.
<http://mcscontrols.com/software.html>
- Bring one of the two connections for laptop to Magnum board.
 - Cross-over Ethernet cable. If laptop has a port for an Ethernet connection, use this.
 - Bring adapter USB port to Cross over Ethernet for laptop
- Through MCS Connect select the ***Ethernet*** option. If a Micro Mag, use ***Local Serial***. Scan for the chiller using the laptop.
- Once connected the model of the chiller will show up on the Laptop.
- Click on the View Only tab and enter four digit password for factory clearance.
(Call Drake Tech Support for this password 215-638-5515).
- Click on the Set Points tab at the bottom right and scroll down to confirm all set points and initial form. (Set points are shown in a list at end of this form)**
- Inspect pump overload settings. (This should match the SFA rating on the pump labels)
- Confirm the process source is capable of providing a load to the chiller.
- Go to the Outputs tab and turn the glycol pump to the *Auto* position. Confirm the phase and proper rotation (Zip-Tie use is recommended)
- Go to the Outputs tab and turn the Distilled water pump to the *Auto* position. Confirm disconnect on heat exchanger is in *ON* position. Confirm the phase and proper rotation (Zip-Tie is recommended).
- Allow the pumps to run and allow the load to bring up 'Chilled Water Out' to 50-75°F.
Monitor this via Inputs tab (Keypad Manual page 6 #4.3)
- From Outputs tab turn the liquid line solenoid 1 (LLS 1), compressor 1 (COMP 1), condenser fan motor 1 (COND 1), condenser fan motor 2 (COND 2), receiver heater 1 (REC HTR 1), receiver heater 2 (REC HTR 2) to *AUTO*
- Any questions at this point call Drake Tech Support 215-638-5515
- Check compressor rotation

- Fill out Log Sheets-Motor chart and Pressure/Temperature chart**

Completion Date:	Service Provider: (1)	Material/tool reference
------------------	--------------------------	-------------------------



Issue Date
3-21-12
Supersedes
8-1-00

File Name
3T.
ACTIVATION.
FORM

Drake Refrigeration Inc. MCS Warranty Activation Form

Schedule Type: Drake Chiller start-up & pm checklist

Page: 3 of 6

- Inspect Condenser fan operation. Check phase (if applicable) and motor rotation if 3 phase power.
- Inspect variable fan speed control is set for 2 clicks from max for Cut out speed and Hard start
- Inspect pressure fan speed control settings to maintain min design head pressure of 235-250 psi.
- Setup the Ord/Ori Valve or other head pressure control to maintain a minimum operating discharge pressure with **All** fans running.
235-240 psi for R407C and 250 psi for R404A
- From Output tab turn All COMP to *MANOFF*. If multiple compressors, do for each. Test All non-digital compressors first. One at a time placing each to MANOFF when complete. Test the digital fully loaded then place unloader into operation. Turn All Compressors to Auto when **superheat setup** is complete.
- Allow pumps to continue to run until the 'Chilled Water Out' is up to 50-75°F again. This can vary. Depends on design.

- Complete the Log sheets**
- Turn Outputs to **AUTO** and confirm everything is in **AUTO**.
- Inspect indoor remote display panel operation.

- Motors, Elements**
- Complete log sheet

- Final checklist**
- Remove all tools and debris from the equipment.
- Replace all service caps and tighten.
- Replace receiver valve stem caps and tighten. (If applicable)
- Replace all chiller manuals and documentation into the electrical panel.
- Install & secure all access panels and hardware.
- Review start up documents with the customer
- Give a copy of the start up documents to the customer
- Fax or email a copy of the start up documents to Drake
(215) 638-5518 or tbartlett@drakechillers.com

<i>Log Sheet (Motors, Elements, etc.)</i>									
ID Information		Amp Readings				Voltage Readings			
Motor/Element Name	% Load	L1	L2	L3	*NP	L1-L2	L1-L3	L2-L3	*NP
Digital Compressor									
Compressor 2									
Condenser Fan 1									
Condenser Fan 2									
Condenser Fan 3									
Condenser Fan 4									
Chiller glycol pump									
Indoor water Pump									
Receiver Heater 1									
Receiver Heater 2									
Liquid Solenoid 1									
Liquid Solenoid 2									

Completion Date:	Service Provider: (1)	Material/tool reference
------------------	--------------------------	-------------------------



Drake Refrigeration Inc. MCS Warranty Activation Form

Issue Date
3-21-12
Supersedes
8-1-00

File Name
3T.
ACTIVATION.
FORM

Schedule Type: Drake Chiller start-up & pm checklist

Page: 4 of 6

*NP=Name Plate

Glycol Freeze Point :

Log Sheet: PRESSURES AND TEMPERATURES

INPUTS	VALUES 1	VALUES 2	VALUES 3	VALUES 4	VALUES 5	VALUES 6	VALUES 7	VALUES 8
SUCT1								
DISCH1								
SUCT2								
DISCH2								
ENT LIQ								
LEV LIQ								
AMBIENT								

Completion Date:	Service Provider: (1)	Material/tool reference
------------------	--------------------------	-------------------------



Drake Refrigeration Inc. MCS Warranty Activation Form

Issue Date
3-21-12
Supersedes
8-1-00

File Name
3T.
ACTIVATION.
FORM

Page: 5 of 6

Schedule Type: Drake Chiller start-up & pm checklist

MCS STATUS SCREEN

PC-Connect for the MCS-8 Status Screen Authorization is at Factory Level

Addr #3, TUE, JUN 13, 06:09:22:45

EDGEWOOD
5
X

RELAY OUTPUTS	VALUE	MANUAL STATUS	LAST ON	LAST OFF	RUN TODAY	CYCLES TODAY	RUN YESTERDAY	CYC YESTERDAY	MAGNUM TEST	SENSOR INPUTS	VALUE	MANUAL STATUS	OFFSET	SENSOR TYPE	LAST ON / MAX TODAY	LAST OFF / MIN TODAY	RUN TDY / CYCLES TODAY	RUN TDY / MAX
M-1 COMP1	ON	AUTO	21:19:23	11:53:32	09:21:24	0	05:35:18	0	M-1 SUCT1	39.9P	AUTO	-3.0P	TI-200	42.8P	37.2P	39.3P	39.3P	
M-2 LOAD1	OFF	AUTO	21:30:27	21:30:27	00:00:00	0	00:00:38	0	M-2 DISC1	201.5P	AUTO	1.0P	TI-500	230.8P	196.1P	215.3P	215.3P	
M-3 UNLOAD1	OFF	AUTO	21:26:28	21:26:28	00:00:00	0	18:24:51	0	M-3 AMPS1	90.1A	AUTO	0.0A	CT-250	98.1A	88.3A	93.5A	93.5A	
M-4 LLS1	ON	AUTO	21:19:43	11:53:15	09:21:24	0	05:34:21	0	M-4 SUCTTMP1	26.5F	AUTO	0.0F	MCS T100	34.2F	24.8F	27.0F	27.0F	
M-5 COMP2	ON	AUTO	21:25:26	11:53:30	09:21:24	0	05:24:14	0	M-5 DISC T100	149.3F	AUTO	0.0F	MCS T100	156.6F	148.6F	153.1F	153.1F	
M-6 LOAD2	OFF	AUTO	09:21:58	09:21:58	00:51:51	3111	00:00:17	0	M-6 MOTFLT1	NO	AUTO		DIGITAL	00:00:00	00:00:00	0	0C	
M-7 UNLOAD2	OFF	AUTO	21:30:44	21:30:44	00:00:00	0	18:35:48	0	M-7 PUMPDW1	NO	AUTO		DIGITAL	00:00:00	00:00:00	0	0C	
M-8 LLS2	ON	AUTO	21:25:46	11:53:14	09:21:24	0	05:23:18	0	M-8 COMP1	164.0P	AUTO	0.0P	TI-500	190.8P	158.5P	176.5P	176.5P	
M-9 FAN1-1	ON	AUTO	21:20:51	11:53:31	09:21:24	0	05:33:05	0	M-9 ENT LIQ	32.6F	AUTO	0.0F	MCS T100	28.9F	29.6F	31.5F	31.5F	
M10 FAN1-2	ON	AUTO	21:20:51	11:53:31	09:21:24	0	05:31:36	0	M10 LEV LIQ	27.2F	AUTO	0.0F	MCS T100	25.8F	24.1F	25.8F	25.8F	
M11 FAN1-3	ON	AUTO	21:21:59	11:53:31	09:21:24	0	05:29:45	0	M11 AMBIENT	75.8F	AUTO	0.0F	MCS T100	85.0F	75.1F	82.0F	82.0F	
M12 FAN1-4	ON	AUTO	21:23:11	11:53:31	09:21:24	0	05:27:46	0	M12 FLOW	YES	AUTO		DIGITAL	00:00:00	00:00:00	0	2C	
M13 FAN1-5	ON	AUTO	21:25:03	11:53:31	09:21:24	0	05:17:01	0	M13 RUN/STOP	RUN	AUTO		DIGITAL	21:18:49	11:53:07	09:21:26	0	0E
M14 FAN2-1	ON	AUTO	21:26:46	11:53:29	09:21:24	0	05:21:18	0	M14 PHASLOSS	NO	AUTO		DIGITAL	00:00:00	00:00:00	00:00:00	0	0C
M15 FAN2-2	ON	AUTO	21:26:52	11:53:29	09:21:24	0	05:21:06	0	M15 SUCT1	38.7P	AUTO	0.0P	TI-200	46.8P	36.0P	39.8P	39.8P	
M16 FAN2-3	ON	AUTO	21:27:43	11:53:29	09:21:24	0	05:18:40	0	M16 DISC2	209.1P	AUTO	0.0P	TI-500	243.2P	198.1P	225.0P	225.0P	
M17 FAN2-4	ON	AUTO	21:29:31	11:53:29	09:21:24	0	05:16:30	0	M17 AMPS2	87.3A	AUTO	0.0A	CT-250	98.1A	84.2A	92.0A	92.0A	
M18 FAN2-5	ON	AUTO	21:30:33	11:53:29	09:21:24	0	05:14:08	0	M18 SUCTTMP2	23.5F	AUTO	0.0F	MCS T100	32.8F	21.8F	26.9F	26.9F	
M19 FAN2-5	ON	AUTO	21:30:33	11:53:29	09:21:24	0	05:14:08	0	M19 DISC TMP2	109.0P	AUTO	0.0P	MCS T100	164.8P	104.2P	135.2P	135.2P	
M20 FAN2-5	ON	AUTO	21:30:33	11:53:29	09:21:24	0	05:14:08	0	M20 MOTFLT2	NO	AUTO		DIGITAL	00:00:00	00:00:00	00:00:00	0	0C
M21 EXV1	36.3%	AUTO							M21 PUMPDW2	NO	AUTO		DIGITAL	00:00:00	00:00:00	00:00:00	0	0C
M22 EXV2	36.0%	AUTO							M22 COMP2	184.1P	AUTO	0.0P	TI-500	206.0P	170.1P	192.9P	192.9P	
M23 EXV2	36.0%	AUTO							M23 SPARE2-1	0	SPARE	0	SPARE	-989	-989	-989	-989	
M24 EXV2	36.0%	AUTO							M24 SPARE2-2	0	SPARE	0	SPARE	-989	-989	-989	-989	
M25 EXV2	36.0%	AUTO							M25 SPARE2-3	0	SPARE	0	SPARE	-989	-989	-989	-989	

ANALOG OUTPUTS	VALUE	MANUAL STATUS	MAX TODAY	MIN TODAY	AVG TODAY	MAX YDY	MIN YDY	AVG YDY
M-1 EXV1	36.3%	AUTO	37.0%	33.0%	34.7%	44.0%	0.0%	8.0%
M-2 EXV2	36.0%	AUTO	38.0%	27.0%	32.4%	34.0%	0.0%	6.0%

Information on Control States and the status of the system.

CAPACITY CONTROL	STATE	WANTED /ACTUAL	STEP DELAY	FLA %	WANTED FLA %	RATE OF CHG	CONTROL ON	MODE
UNIT IS LOADED	12:03:06	2 / 2 of 2	300	100%			0.0	CHILLER
CIRCUIT STATE	TIME	OIL DIFF	FLA %	SLIDE				ACCUM
1) <COMP IS HOLDING	11:56:30	124.1P	100%					4
2) COMP IS HOLDING	01:13:42	146.4P	96%					
CIRCUIT SUCTION TEMP	SATURATED	SUCTION	DISC	SATURATED	DISC			
1) 26.5	16.9	9.6	149.3	101.8	47.5			Ref Type is R22
2) 23.5	15.7	7.8	108.8	104.1	4.7			
DEFROST STATE	TIME	VALVE %	SUPERHEAT	SHEAT ROC	ADD DELAY			
1) EXV IS HOLDING	00:21:50	35.3%	9.7	0.0	80			
2) EXV IS CLOSING	00:00:24	36.6%	7.8	0.0	56			

STATUS: ALIMS (ST Pts) / RESET/CLEAR

EXIT SYS INF PRT->File GRAPH TRANSMIT RECEIVE METER SCHED DIAG AUTH

start PC-Connect 9:22 AM

Completion Date:

Service Provider:

(1)

Material/Tool reference



Drake Refrigeration Inc. MCS Warranty Activation Form

Issue Date
3-21-12
Supersedes
8-1-00

File Name
3T.
ACTIVATION.
FORM

Schedule Type: Drake Chiller start-up & pm checklist

Page: 6 of 6

Notes:

Completion Date:	Service Provider: (1)	Material/tool reference
------------------	--------------------------	-------------------------



WARRANTY LABOR ALLOWANCES

MUST BE APPROVED TO RECEIVE COMPENSATION

Service Category	Task Description	Man Hours
Electrical	Replace HOST micro-processor controller	1.00
	Replace REMOTE micro-processor controller	1.00
	Replace High or Low pressure controller transducer with cable	1.00
	Replace compressor or fan contactor	1.00
	Replace pump motor contactor/overload and calibrate to SF amps	1.00
	Replace differential flow safety	1.00
	Replace compressor crank case heater (insert or band)	1.00
	Replace receiver heater Scroll system	2.50
	Replace receiver heater Semi-Hermetic system	3.50
	Replace evaporator heater (Braze Plate)	2.00
	Replace evaporator heater (Shell and Tube)	2.50
	Replace condenser fan motor	1.00
	Replace refrigerant solenoid coil	1.00
	Replace flooded condenser heater controller	1.00
	Refrigeration	Replace compressor (Scroll)
Replace compressor semi-hermetic		8.00
Replace TXV standard		3.00
Replace liquid line solenoid valve standard		5.00
Replace liquid line solenoid flooded condenser		2.00
Replace head master valve		5.00
Fluid Systems	Replace Recirculation pump	3.00
	Replace System pump	3.00
	Replace Pump Seal on Recirc or System	2.00
	Replace tank level sight glass lenses	1.00
Leak Repairs	Refrigeration piping braze joint (15% silfos)	4.00
	Fluid piping braze joint (95/5 solder)	2.00
	Pipe to fitting joint repair (Refrigeration or Fluid)	2.00
	Fluid pipe to Braze Plate evaporator	3.00
	Fluid pipe to shell and tube evaporator	3.00



2900 Samuel Drive | Bensalem, PA 19020
888-289-7299 | 215-638-5515

www.drakechillers.com



Intertek

Manufactured with pride in the USA.

Drake Installation Manual 10/2018